Technical Data Lambda Probe LS2 ECO



Fig. 1 Lambda Probe LS2 ECO





Fig. 2 Lambda Probe LS2 ECO (dimensions in mm)

1	Lambda Probe LS2 ECO
2	Locking ring for GED ECO
3	Probe head



- 1 (+) Probe signal (black) (PCB/LT2 term. 34)
- 2 (-) Probe signal (grey) (PCB/LT2 term. 33)
- 3 Socket sensor signal
- 4 Probe heater (white) (PCB/LT2 term. 35)
- 5 Plug probe heater
- 6 Probe heater (white) (PCB/LT2 term. 36)




Fig. 3 Terminal assignment probe connection plug

Technical Data Lambda Probe LS2 ECO

Technical data*		
Measuring range	O₂ : 0 21 % O ₂	
Measuring precision	$\mathbf{O_2}$: $\pm5\%$ of measured value - not better than ±0.3 vol. $\%$	
Sensor signal	O₂: -30 +150 mV	
Response time	O₂: t ₆₀ : < 3 s	
	t ₉₀ : < 9 s	
Relaxation time (measurement readiness after overload)	O₂: t ₉₀ : < 8 s	
Offset in ambient air	O₂: < 0.3 vol. %	
Repeat accuracy	O ₂ : < 0.1 % deviation from measured value	
Drift	O₂: < 1.7 % from measured value (after 1000 h of operation in EL light fuel oil and 1004 switching cycles ON/OFF)	
Cross sensitivity**	O₂: to CO ₂ (15 vol. %) < 0.1 vol. %	
	O₂: to CO (874 ppm) < 0.1 vol. %	
	O₂: to CH ₄ (76 ppm) < 0.1 vol. %	
	O₂: to SO ₂ (76 ppm) < 0.1 vol. %	
	O₂: to NO (245 ppm) < 0.1 vol. %	
Heating consumption	10 25 W (according to design, measuring gas temperature, and measuring speed)	
Lifetime	> 3 years (in case of light fuel oil and natural gas)	
Weight	560 g 1.23 lb	
Material of probe housing	1.4571/1.4301	
Material of connecting line	Nickel-plated copper strand FEP insulation	
Operating temperature of the measuring cell (sensor) at 13 V heating voltage in the air (20 °C 68 °F)	650 °C 1,202 °F	
Measuring principle	Zirconium dioxide cell (ZrO ₂) potentiometric (voltage probe)	
Heating time	10 minutes until operating temperature is reached	

^{*} Information according to EN 16340:2014 D

^{**} O_2 : Information assumes an operating gas composition of 5 vol. % O_2 , rest is N_2

Conditions for use				
Mounting / measuring gas extraction device	Directly in exhaust gas channel / in situ			
Seal tightness	$q_L \le 100 \text{ cm}^3/\text{h} / 6.10 \text{ in}^3/\text{h} *$			
Mounting position	Horizontal to vertical			
Permissible fuels	Residue-free, gaseous hydrocarbons, light fuel oil			
Ideal measuring gas speed	Without GED: 1 m/s \leq X \leq 4 m/s			
	with GED ECO: 1 m/s ≤ X ≤ 6 m/s			
	(Higher measuring gas speed increases the measurement error. Measured at measuring gas temperature 25 °C 77 °F. In case of smaller measuring gas temperatures it might be necessary to protect the probe from the incident flow.)			
Reference air supply	Not required			
Flange adapter	Male coupling G1¼"			

Technical Data Lambda Probe LS2 ECO

Environmental Conditions					
Probe head	permissible flue gas tempera- ture	≤ 300 °C 572 °F			
Operation	permissible temperature	≤ 260 °C 500 °F at connecting cable			
Transport	permissible temperature	-20 +70 °C -4 °F +158 °F			
Storage	permissible temperature	-20 +70 °C -4 °F +158 °F			
Degree of protection	DIN EN 40050	IP42			

 ^{*} According to DIN V 18160-1:2006-01, seal tightness towards environment through housing and fastening.

NOTICE

The limits of the technical data must be strictly adhered to.

Order Information

Lambda Probe LS2 for measurement of oxygen (O₂), for flue gas temperatures up to 300 °C | 572 °F with connecting cable

Description / Type	Order no.
Lambda Probe LS2 ECO (in standard housing), cable length 2 m 6.6 ft, IP42*	650R1000
Lambda Probe LS2 ECO (in standard housing), cable length 5 m 16.4 ft, IP42*	650R1007

Additional required: Lambda Transmitter LT3, conf. for LS2 in type

Order no. 657R51 / ... / LS2 / ...

Gas extraction device GED ECO, order no. 655R1001 / R1002 / R1003

Probe installation fitting (PIF), order no. 655R1010 or R1016

The information in this publication is subject to technical changes.

LAMTEC Meß- und Regeltechnik für Feuerungen GmbH & Co. KG

Josef-Reiert-Straße 26 D-69190 Walldorf

Telefon: +49 (0) 6227 6052-0 Telefax: +49 (0) 6227 6052-57

info@lamtec.de www.lamtec.de

